

PORCELANOSA Grupo

shower deck

The completely flat shower tray

butech
PORCELANOSA Grupo

shower deck

New concept shower tray with hidden drain for the most exclusive bathrooms. This new shower-tray system creates a sense of continuity with the rest of the bathroom floor because the slopes are hidden under the floor. Drainage is achieved through open joints and does not require a drainage grille.

The **shower deck** system is a shower consisting of a polyurethane base coated with thermostable polymer, ready for ceramic tiles without any need for adhesive. Especially recommended for bathroom refurbishments.

shower deck

TECHNICAL INFO

Main characteristics

- Flat shower tray without slopes.
- Polyurethane coated with thermostable polymers.
- Sump drain hidden from view.
- Ultrathin shower tray; only 30 mm high.
- Easy cleaning and high resistance to household detergents.
- Virtually zero maintenance, especially in comparison with wooden flooring.
- Thermal insulation.
- Easy installation and assembly.

Recommended uses

- Shower trays and cubicles for all types of bathrooms.
- Shower trays for private and public use.
- Bathrooms adapted for people with reduced mobility.
- Bathrooms for the disabled.

shower deck TRAY COMPONENTS



1. Shower deck. Thickness: 30mm
2. Non-return horizontal siphonic drain. Height 60mm. Outlet \varnothing 40mm and 0.52 l/s
3. Drain reinforcement piece.
4. lamiband 200, 5 linear meters roll (1 unit)
5. imperband 5 linear meters roll (1 unit)
6. PVC LEVELLING profiles 14X14X2 pcs of the Length + 1 unit of the Width (Max. 2,000 mm) (3 units).
7. Connection profiles for tiles 30x4xLength of the tray, max. 2,000mm (2 pcs.)
8. p-404 tube
9. Protection sheet
10. Tile lifting tool
11. Instructions

shower deck
UNLIMITED BATHROOM
DESIGN



Nobu Roble Ant 19,3x180 cm

Shower deck tray 121,6x93,8 cm



Manhatan Colonial anti-slip 19.3 x 180 cm

Shower deck tray 80x120 cm



Oxford castaño 22x90 cm

Shower deck tray 121,6x93,8 cm



Newport beige 33,3x100 cm

Shower deck tray 80x93,8 cm




Houston taupe 120x29,4

Shower deck tray 121,6x93,8 cm



Montana honey 19,3x120 cm

Shower deck tray 121,6x93,8 cm



Ascot Arce 29.4X120 cm

Shower deck tray 121,6x93,8 cm




Manhattan cognac 29,4x180 cm

Shower deck tray 121,6x93,8 cm


shower deck SELECTING THE SHOWER TRAY

Lateral shower head less than or equal to 35 cm




Recommended **shower deck**: 800 x 938mm, 900 x 938mm or 1216 x 938mm

Lateral shower head equal to or greater than 35 cm



Recommended **shower deck**: 1216 x 938mm

Central shower head less than or equal to 35 cm



Recommended **shower deck**: 1216 x 938mm

Shower tray selection criteria

The measure of the **shower deck** does not have to exactly match the area of the tray, should only coincide with the area of drainage, where the water falls. Therefore the shower tray will depend on the type of rain/head/hand shower.

Extension of the drainage area: in bathroom renovation, when the drainage area is slightly larger than an available shower deck reference, tiles on the **shower deck** can be combined with a ceramic perimeter fixed to the substrate. In this case, it is recommended to fix the ceramic with a slight slope of 0.5%.




Oxford castaño 22x90 cm

Shower deck tray 121,6x93,8 cm

shower deck INSTALLATION DIAGRAM

Shower deck diagram



The **shower-deck** does not include tiles.

The tiles require a certain mechanical strength, therefore a minimum 10mm thickness is needed. Otherwise, the installation of a reinforcing sheet is required.

Do not use tiles with an absorption greater than 0.5% according to UNE-EN-ISO 10545-3.

shower deck INSTALLATION DETAILS



When the **shower-deck** sits under wall tiles, it is recommended to use the PVC levelling profile (**SAP 250046210**).

With the use of this levelling profile, we increase the distance between the shower-deck tiles and the wall, avoiding possible damage during lifting and handling.



For a correct separation between the **shower-deck** tiles, it's recommended leaving a 4mm open joint between each tile (**SAP 100225510**).

To ease handling and to reduce the weight to be lifted, cut the connection profile to divide the layout in groups of two tiles. If there are mismatched pieces, place them on the end of the shower-deck which is closest to the wall. These pieces must also have the connection profile underneath.



As in other shower systems, the planimetry in the installation of the **shower-deck** is crucial.


It is required that the shower-deck does not fit forcefully or under pressure. The support where the installation is going to be carried out must be completely flat, levelled and with a solid base, in order to achieve a proper installation of the tiles on top.

Once the installation is finished, seal the perimeter joints.

shower deck HOW TO PLACE AN ORDER

Information needed to place a **shower deck** order:

- Shower tray length (mm): maximum length 3000 mm
- Shower tray width (mm): maximum width 1500 mm
- Sump Position. Recommended distance to either side: 300 mm



The **shower deck** kit includes a horizontal drain with non-return valve. When a different drain is needed, use one of the following references:

- | | |
|-----------|--|
| 250045810 | Horizontal SWD drain with standard valve |
| 250049540 | Vertical SWD drain with standard valve |
| 250049695 | High flow SWD drain + non-return valve |

shower deck CUSTOM SHOWER TRAY

Standard references of shower deck

For special measures trays, use: 100174848 SHOWER DECK TRAY SPECIAL MEASUREMENTS

PAR-KER® smart 22 x 90 cm

Shower Tray Measures

N° of pieces	Length (mm)	Length (mm)
3	706	938
4	930	938
5	1154	938
6	1378	938
7	1602	938
8	1826	938

Not available in stock, make to order.

PAR-KER® 19,3 x 120 cm

Shower Tray Measures

N° of pieces	Length (mm)	Length (mm)
4	822	1238
5	1019	1238
6	1216	1238
7	1413	1238
8	1610	1238
9	1807	1238

Not available in stock, make to order.

VENIS PROJECTS *	PORCELANOSA
FOREST	MINNESOTA
	TANZANIA
	VANCOUVER

* For VENIS PROJECTS ceramics, consult conditions.

Calculations for 4 mm joints

shower deck CUSTOM SHOWER TRAY

Standard references of shower deck

For special measures trays, use: 100174848 SHOWER DECK TRAY SPECIAL MEASUREMENTS

PAR-KER® 19,3 x 180 cm

Shower Tray Measures

N° of pieces	Length (mm)	Width (mm)
3	890	≤1838
4	1188	≤1838
5	1486	≤1838
6	1784	≤1838

PORCELANOSA
DELAWARE
DEVON
MANHATTAN
MINNESOTA
NOBU
TANZANIA

PAR-KER® 25 x 150 cm

Shower Tray Measures

N° of pieces	Length (mm)	Width (mm)
3	796	1538
4	1050	1538
5	1304	1538
6	1558	1538
7	1812	1538

PORCELANOSA
MINNESOTA
NEBRASKA
TANZANIA
VANCOUVER

Not available in stock, make to order.

Calculations for 4 mm joints



BY APPOINTMENT TO
H.R.H. THE PRINCE OF WALES
MANUFACTURER AND DISTRIBUTOR
OF CERAMIC TILES AND BUILDING PRODUCTS.
PORCELANOSA GROUP LIMITED

PORCELANOSA Grupo

butech
PORCELANOSA Grupo

butech building technology s.a.u.

Carretera Vila-real - Puebla de Arenoso CV-20 Apt./Box 297 12540 · Vila-real (Castellón) · Spain
Teléfono: (+34) 964 536 200 · Fax: 964 530 034 (Nacional) · Fax: (+34) 964 530 034 (Internacional)
e-mail: butech@butech.es
www.butech.net